




Rod mount fixture: Use the swivel included or the swivel from your fixture kits. Do not use plastic connectors.

Cord mount fixture: Use the plastic connectors included or use the plastic connectors from your fixture kits. Do not use the swivels.

Chain mount fixture: if your fixture is chain mounted do not use the swivel or plastic connectors, you will need to use the chain and loops from your fixture. This product does not come with loops, if you do not have proper loops to attach the chain, please contact your lighting supplier or Z-Lite as the loops are sold separately.

1-Fasten mounting plate to the outlet box and using wood or metal screws to the building structure at ends of the mounting plate prevent sagging.

2-Estimate height of fixtures and prepare rods, cord, or chain needed to achieve your desired height.

3-Follow fixture directions for cord, rod, or chain preparation and installation.

4-For Rod installation fasten swivel to top of rod set.

5-thread wires or cord through the face plate of the ceiling plate.

6-prepare wires and connect them to building wiring as per instructions included with fixture kits.

7-Once wire connections are finished carefully tuck in wires and lift the face plate up to the ceiling mounting plate and fasten with the side screws.

8-Tighten the side screws to fasten the faceplate to the mounting plate.