

CHAIN PENDANT FIXTURE INSTALLATION INSTRUCTIONS FOR #220-16

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Take the parts out of the mounting package and thread the HEX NUT (7) several turns onto the NIPPLE (6). Attach the NIPPLE (6) to the support beam and protruding 1/2" inside the center hole of the top of the OUTLET BOX (2). (See Fig. 1)
2. Thread both HEX NUTS (14) several turns onto each end of the NIPPLE (15). Attach the HICKEY (9) and NIPPLE (15), as shown above to the NIPPLE (6), pull the SUPPLY WIRE (3) and SUPPLY GROUND WIRE (10) out from the OUTLET BOX (2). (See Fig. 1)
3. Thread both HEX NUTS (14) and the SCREW COLLAR LOOP (16) onto the NIPPLE (15) and that is facing down, but do not tighten the HEX NUT (14). Place the CANOPY (17) over the OUTLET BOX (2) and adjust the SCREW COLLAR LOOP (16) and NIPPLE (15) until the outside thread on the SCREW COLLAR LOOP (16) is centered with the center hole opening of the CANOPY (17). Take away the CANOPY (17) and tighten the HEX NUT (14) and the SCREW COLLAR LOOP (16). (See Fig. 1)
4. Thread the CENTER TUBE(21) onto the NIPPLE(25) till tight. Pull the ARMS so they are evenly spaced. (See Fig. 2)
5. Open up the end links of the CHAIN (19) and attach one end of the CHAIN (19) onto the FIXTURE LOOP (20) which is already pre-assembled to the lamp body. Slide the THREADED RING (18) and the CANOPY (17) onto the CHAIN (19) (in that order) and attach the other end of the CHAIN (19) to the SCREW COLLAR LOOP (16). Close the ends of the chain links. (See Fig. 1 and 2)
6. Unravel the fixture lead wires and FIXTURE GROUND WIRE (12) and thread them through every other link of the CHAIN (19) and out through the SCREW COLLAR LOOP (16), then through the NIPPLE (15) and HICKEY (9) assembly, starting with the chain link attach to the FIXTURE LOOP (20). (See Fig. 1)
7. Feed the SAFETY CABLE (5) starting with the chain link attach to the SCREW COLLAR LOOP (16), then through the NIPPLE (15), HICKEY (9) and the hole of the OUTLET BOX (2) to be attached it to the structure support beam of the building.

ASSEMBLY AND INSTALLATION (Continued)

8. Attach the power supply wires to the fixture lead wires by connecting the BLACK SUPPLY WIRE to the SMOOTH FIXTURE LEAD WIRE and the WHITE SUPPLY WIRE to the RIBBED FIXTURE LEAD WIRE. Attach the FIXTURE GROUND WIRE (12) to the SUPPLY GROUND WIRE (10) by the WIRE NUT (11). Place wiring and connections inside the OUTLET BOX(2). (See Fig. 1)
9. Slide the CANOPY (17) and the THREADED RING (18) up the CHAIN (19). Place the CANOPY (17) over the OUTLET BOX (2) and secure it in place by screwing the THREADED RING (18) onto the SCREW COLLAR LOOP (16). (See Fig. 1)
10. Slide the GLASS SHADE(23) over the SOCKET(24), secure with the SOCKET RING(22).
11. Screw light bulbs into the lamp sockets and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating label, **MAXIMUM 60W.**

INSTALLATION IS NOW COMPLETED

